

# Rollo Talks via Colors!

## Label LED



### Green

All set and ready to impress you with my printing skills!



### Red - Blinking

I'm having trouble with the label.

Please load in labels then press and hold the "r" button until you hear one beep. If labels keep feeding, switch me off to clear any pending jobs and try this again.

## Wireless LED



### White

I'm ready to be setup.

Use the Rollo App to set me up!



### Blue

I'm connected to Wi-Fi and ready to receive your print jobs!

Blinking Blue means I'm trying to connect to Wi-Fi.



### Red

I'm not connected to your Wi-Fi!

Please check your Wi-Fi or rapidly press the red light 10 times to factory reset me.



### Green - Blinking

I'm updating.

When I don't have any print jobs, I will restart.



### Purple - Blinking

I am receiving a print job. Woo-hoo!



### Purple and Yellow - Alternating

I am getting ready. Give me just a moment.